



Changes for the Better

FX3U SERIES PROGRAMMABLE CONTROLLERS

HARDWARE MANUAL

Manual Number	JY997D18801
Revision	K
Date	May 2011



This manual describes the part names, dimensions, mounting, cabling and specifications for the product. This manual is extracted from FX3U Series User's Manual - Hardware Edition. Refer to FX3U Series User's Manual - Hardware Edition for more details. Before use, read this manual and manuals of relevant products fully to acquire proficiency in the handling and operating the product. Make sure to learn all the product information, safety information, and precautions.

And, store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

Registration

The company name and the product name to be described in this manual are the registered trademarks or trademarks of each company.

Effective May 2011

Specifications are subject to change without notice.

© 2005 Mitsubishi Electric Corporation

Safety Precaution (Read these precautions before use.)

This manual classifies the safety precautions into two categories:

**DANGER** and **CAUTION**.

<b>DANGER</b>	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
<b>CAUTION</b>	Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Depending on the circumstances, procedures indicated by **CAUTION** may also cause severe injury.

It is important to follow all precautions for personal safety.

<b>STARTUP AND MAINTENANCE PRECAUTIONS</b>	<b>DANGER</b>
<ul style="list-style-type: none"> <li>Do not touch any terminal while the PLC's power is on. Doing so may cause electric shock or malfunctions.</li> <li>Before cleaning or retightening terminals externally cut off all phases of the power supply. Failure to do so may cause electric shock.</li> </ul>	

<b>STARTUP AND MAINTENANCE PRECAUTIONS</b>	<b>DANGER</b>
<ul style="list-style-type: none"> <li>Use the battery for memory backup correctly in FX3U Series User's Manual - Hardware Edition.                     <ul style="list-style-type: none"> <li>Use the battery only for the specified purpose.</li> <li>Connect the battery correctly.</li> <li>Do not charge, disassemble, heat, put in fire, short-circuit, connect reversely, weld, swallow or burn the battery, or apply excessive forces (vibration, impact, drop, etc.) to the battery.</li> <li>Do not store or use the battery at high temperatures or expose to direct sunlight.</li> <li>Do not expose to water, bring near fire or touch liquid leakage or other contents directly.</li> <li>Incorrect handling of the battery may cause heat excessive generation, bursting, ignition, liquid leakage or deformation, and lead to injury, fire or failures and malfunctions of facilities and other equipment.</li> </ul> </li> <li>Before modifying or disrupting the program in operation or running the PLC, carefully read through this manual and the associated manuals and ensure the safety of the operation. An operation error may damage the machinery or cause accidents.</li> </ul>	

<b>STARTUP AND MAINTENANCE PRECAUTIONS</b>	<b>CAUTION</b>
<ul style="list-style-type: none"> <li>Turn off the power to the PLC before attaching or detaching the memory cassette. If the memory cassette is attached or detached while the PLC's power is on, the data in the memory may be destroyed, or the memory cassette may be damaged.</li> <li>Do not disassemble or modify the PLC. Doing so may cause fire, equipment failures, or malfunctions. For repair, contact your local Mitsubishi Electric distributor.</li> <li>Turn off the power to the PLC before connecting or disconnecting any extension cable. Failure to do so may cause equipment failures or malfunctions.</li> <li>Turn off the power to the PLC before attaching or detaching the following devices. Failure to do so may cause equipment failures or malfunctions.                     <ul style="list-style-type: none"> <li>Display module, peripheral devices, expansion boards, and special adapters</li> <li>Connector conversion adapter, extension blocks, and FX Series terminal blocks</li> <li>Battery and memory cassette</li> </ul> </li> </ul>	

<b>DISPOSAL PRECAUTIONS</b>	<b>CAUTION</b>
<ul style="list-style-type: none"> <li>Please contact a certified electronic waste disposal company for the environmentally safe recycling and disposal of your device. When disposing of batteries, separate them from other waste according to local regulations. (For details of the Battery Directive in EU countries, refer to FX3U Series User's Manual - Hardware Edition.)</li> </ul>	

<b>TRANSPORTATION AND STORAGE PRECAUTIONS</b>	<b>CAUTION</b>
<ul style="list-style-type: none"> <li>Before transporting the PLC, turn on the power to the PLC to check that the BATT LED is off. If the PLC is transported with the BATT LED on or the battery exhausted, the battery-backed data may be unstable during transportation.</li> </ul>	

2	<b>TRANSPORTATION AND STORAGE PRECAUTIONS</b>	<b>CAUTION</b>
<ul style="list-style-type: none"> <li>The PLC is a precision instrument. During transportation, avoid impacts larger than those specified in Section 2.1. Failure to do so may cause failures in the PLC. After transportation, verify the operations of the PLC.</li> <li>When transporting lithium batteries, follow required transportation regulations. (For details of the regulated products, refer to FX3U Series User's Manual - Hardware Edition.)</li> </ul>		

<b>Marine standard</b>
<p>Please consult with Mitsubishi Electric for the information on marine standard practices and the corresponding types of equipment.</p>

<b>Certification of UL, cUL standards</b>
<p>FX3U series main units, FX3U series special adapters and FX2N series input/output extension units/blocks supporting UL, cUL standards are as follows:</p>

**UL, cUL file number :E95239**

**Models : MELSEC FX3U series manufactured**

FX3U-★MR/ES(-A)	FX3U-★MT/ES(-A)
FX3U-★MT/ESS	
Where ★★ indicates:16,32,48,64,80,128	
FX3U-★MR/DS	FX3U-★MT/DS
FX3U-★MT/DSS	
Where ★★ indicates:16,32,48,64,80	
FX3U-★MR/UA1	FX3U-★MS/ES
Where ★★ indicates:32,64	
FX3U-232ADP(-MB)	FX3U-485ADP(-MB)
FX3U-4AD-ADP	FX3U-4DA-ADP
FX3U-3A-ADP	FX3U-4AD-PT-ADP
FX3U-4AD-PTW-ADP	FX3U-4AD-PNK-ADP
FX3U-4AD-TC-ADP	
FX3U-4HSX-ADP	FX3U-2HSY-ADP
FX3U-CF-ADP	

**Models : MELSEC FX2N series manufactured**

FX2N-★ER-ES/UL	FX2N-★ET-ESS/UL
Where ★★ indicates:32,48	
FX2N-48ER-DS	FX2N-48ET-DSS
FX2N-48ER-UA1/UL	
FX2N-8ER-ES/UL	FX2N-8EX-ES/UL
FX2N-8EYR-ES/UL	FX2N-8EYR-S-ES/UL
FX2N-8EYT-ESS/UL	FX2N-8EX-UA1/UL
FX2N-16EX-ES/UL	FX2N-16EYR-ES/UL
FX2N-16EYT-ESS/UL	FX2N-16EYS

**Compliance with EC directive(CE Marking)**

This document does not guarantee that a mechanical system including this product will comply with the following standards. Compliance to EMC directive and LVD directive of the entire mechanical system should be checked by the user / manufacturer. For more details please contact the local Mitsubishi Electric sales site.

**Requirement for Compliance with EMC directive**

The following products have shown compliance through direct testing (of the identified standards below) and design analysis (through the creation of a technical construction file) to the European Directive for Electromagnetic Compatibility (2004/108/EC) when used as directed by the appropriate documentation.

**Attention**

- This product is designed for use in industrial applications.

**Note**

- Manufactured by: Mitsubishi Electric Corporation 2-7-3 Marunouchi, Chiyoda-ku, Tokyo, 100-8310 Japan
- Manufactured at: Mitsubishi Electric Corporation Himeji Works 840 Chiyoda-machi, Himeji, Hyogo, 670-8677 Japan
- Authorized Representative in the European Community: Mitsubishi Electric Europe B.V. (For details of the regulated products, refer to FX3U Series User's Manual - Hardware Edition, Germany. Gothaer Str. 8, 40880 Ratingen, Germany.)

**Type : Programmable Controller (Open Type Equipment)**

**Models : MELSEC FX3U series manufactured**

from May 1st, 2005	FX3U-★MR/ES(-A)	Where ★★ indicates:16,32,48,64,80
	FX3U-4HSX-ADP	FX3U-2HSY-ADP
	FX3U-FLROM-16	FX3U-FLROM-64L
	FX3U-7DM	
from June 1st, 2005	FX3U-232ADP	FX3U-485ADP
	FX3U-4AD-ADP	FX3U-4DA-ADP
	FX3U-4AD-PT-ADP	FX3U-4AD-TC-ADP
	FX3U-232-BD	FX3U-422-BD
	FX3U-485-BD	FX3U-USB-BD
	FX3U-FLROM-64	FX3U-CNV-BD
from November 1st, 2005	FX3U-★MT/ES(-A)	Where ★★ indicates:16,32,48,64,80
	FX3U-★MT/ESS	
from February 1st, 2006	FX3U-128MT/ES(-A)	FX3U-128MT/ES(-A)
	FX3U-★MR/DS	FX3U-★MT/DS
	FX3U-★MT/DSS	
from April 1st, 2007	FX3U-232ADP-MB	FX3U-485ADP-MB
from December 1st, 2007	FX3U-4AD-PTW-ADP	FX3U-4AD-PNK-ADP
from June 1st, 2009	FX3U-3A-ADP	FX3U-CF-ADP
from August 1st, 2010	FX3U-8AV-BD	
from September 1st, 2010	FX3U-★MR/UA1	FX3U-★MS/ES
	Where ★★ indicates:32,64	
from May 1st, 2011	FX3U-FLROM-1M	

Standard	Remark
EN61131-2:2007 Programmable controllers - Equipment requirements and tests	Compliance with all relevant aspects of the standard. EMI
	<ul style="list-style-type: none"> <li>Radiated Emission</li> <li>Conducted Emission</li> </ul>
	EMS
	<ul style="list-style-type: none"> <li>Radiated electromagnetic field</li> <li>Fast Transient burst</li> <li>Electrostatic discharge</li> <li>High-energy surge</li> <li>Voltage drops and interruptions</li> <li>Conducted RF</li> <li>Power frequency magnetic field</li> </ul>

**Models : MELSEC FX2N series manufactured**

from July 1st, 1997	FX2N-★ER-ES/UL	FX2N-★ET-ESS/UL
	Where ★★ indicates:32,48	
	FX2N-16EX-ES/UL	FX2N-16EYR-ES/UL
	FX2N-16EYT-ESS/UL	
from April 1st, 1998	FX2N-48ER-DS	FX2N-48ET-DSS
from August 1st, 1998	FX2N-48ER-UA1/UL	
from August 1st, 2005	FX2N-8ER-ES/UL	FX2N-8EX-ES/UL
	FX2N-8EYR-ES/UL	FX2N-8EYT-ESS/UL
from September 1st, 2010	FX2N-8EYR-S-ES/UL	

For the products above, PLCs manufactured before March 31st, 2002 are compliant with EN50081-2 (EN61000-6-4) and EN50082-2

from April 1st, 2002 to April 30th, 2006 are compliant with EN50081-2 (EN61000-6-4) and EN61131-2:1994+A11:1996+A12:2000 after May 1st, 2006 are compliant with EN61131-2:2007

Standard	Remark
EN61000-6-4:2007 - Generic emission standard Industrial environment EN50081-2:1993 Electromagnetic compatibility	Compliance with all relevant aspects of the standard. • Emission-Enclosure port • Emission-Low voltage AC mains port • Emission-Telecommunications/network port
EN50082-2:1995 Electromagnetic compatibility - Generic immunity standard Industrial environment	Compliance with all relevant aspects of the standard. • RF immunity • Fast Transients • ESD • Conducted • Power magnetic fields
EN61131-2:1994 /A1:1996 /A12:2000 Programmable controllers - Equipment requirements and tests	Compliance with all relevant aspects of the standard. • Radiated electromagnetic field • Fast transient burst • Electrostatic discharge • Damped oscillatory wave
EN61131-2:2007 Programmable controllers - Equipment requirements and tests	Compliance with all relevant aspects of the standard. EMI • Radiated Emission • Conducted Emission EMS • Radiated electromagnetic field • Fast Transient burst • Electrostatic discharge • High-energy surge • Voltage drops and interruptions • Conducted RF • Power frequency magnetic field

**Requirement for Compliance with LVD directive**

The following products have shown compliance through direct testing (of the identified standards below) and design analysis (through the creation of a technical construction file) to the European Directive for Low Voltage (2006/95/EC) when used as directed by the appropriate documentation.

**Type : Programmable Controller (Open Type Equipment)**  
**Models : MELSEC FX3U series manufactured**

from May 1st, 2005 FX3U-★\*MR/ES(-A)  
Where ★★ indicates:16,32,48,64,80

from November 1st, 2005 FX3U-★\*MT/ES(-A)  
FX3U-★\*MT/ESS  
Where ★★ indicates:16,32,48,64,80

from February 1st, 2006 FX3U-128MR/ES(-A)  
FX3U-128MT/ES(-A)  
FX3U-128MT/ESS  
FX3U-★\*MR/DS  
Where ★★ indicates:16,32,48,64,80

from September 1st, 2010 FX3U-★\*MR/UA1  
FX3U-★\*MS/ES  
Where ★★ indicates:32,64

Standard	Remark
EN61131-2:2007 Programmable controllers - Equipment requirements and tests	The equipment has been assessed as a component for fitting in a suitable enclosure which meets the requirements of EN61131-2:2007

**Models :MELSEC FX2N series manufactured**

from July 1st, 1997 FX2N-★\*ER-ES/UL FX2N-★\*ET-ESS/UL  
Where ★★ indicates:32,48  
FX2N-16EYR-ES/UL

from April 1st, 1998 FX2N-48ER-DS

from August 1st, 1998 FX2N-48ER-UA1/UL

from August 1st, 2005 FX2N-8ER-ES/UL FX2N-8EYR-ES/UL

from September 1st, 2010 FX2N-8EYR-S-ES/UL

For the products above, PLCs manufactured before March 31st, 2002 are compliant with IEC1010-1 from April 1st, 2002 to April 30th, 2006 are compliant with EN61131-2:1994+A11:1996+A12:2000 after May 1st, 2006 are compliant with EN61131-2:2007

Standard	Remark
IEC1010-1:1990 /A1:1992 Safety requirements for electrical equipment for measurement, control, and laboratory use - General requirements	The equipment has been assessed as a component for fitting in a suitable enclosure which meets the requirements of IEC 1010-1:1990+A1:1992
EN61131-2:1994 :2007 /A12:2000 /A11:1996 Programmable controllers - Equipment requirements and tests	The equipment has been assessed as a component for fitting in a suitable enclosure which meets the requirements of EN61131-2:1994+A11:1996+A12:2000, :2007

**Caution for compliance with EC Directive**

**Installation in Enclosure**

Programmable logic controllers are open-type devices that must be installed and used within conductive control boxes. Please use the FX3U Series programmable logic controllers while installed in conductive shielded control boxes. Please secure the control box lid to the control box (for conduction). Installation within a control box greatly affects the safety of the system and aids in shielding noise from the programmable logic controller.

**Caution for Analog Products in use**

The analog special adapters have been found to be compliant to the European standards in the aforesaid manual and directive. However, for the very best performance from what are in fact delicate measuring and controlled output device Mitsubishi Electric would like to make the following points;  
As analog devices are sensitive by nature, their use should be considered carefully. For users of proprietary cables (integral with sensors or actuators), these users should follow those manufacturers installation requirements.  
Mitsubishi Electric recommend that shielded cables should be used. If NO other EMC protection is provided, then users may experience temporary induced errors not exceeding +10%/-10% in very heavy industrial areas.  
However, Mitsubishi Electric suggest that if adequate EMC precautions are followed with general good EMC practice for the users complete control system, users should expect normal errors as specified in this manual.

- Sensitive analog cable should not be laid in the same trunking or cable conduit as high voltage cabling. Where possible users should run analog cables separately.
- Good cable shielding should be used. When terminating the shield at Earth - ensure that no earth loops are accidentally created.

- When reading analog values, EMC induced errors can be smoothed out by averaging the readings. This can be achieved either through functions on the analog special adapter/block or through a users program in the FX3U Series PLC main unit.

**Associated manuals**

FX3U Series PLC (main unit) comes with this document (hardware manual).

For a detailed explanation of the FX3U Series hardware and information on instructions for PLC programming and special extension unit/block, refer to the relevant documents.

Manual name	Manual No.	Description
FX3U Series User's Manual - Hardware Edition	JY997D16501 MODEL CODE: 09R516	Explains FX3U Series PLC specification details for I/O, wiring, installation, and maintenance.
FX3G/FX3U/FX3UC Series Programming Manual - Basic & Applied Instruction Edition	JY997D16601 MODEL CODE: 09R517	Describes PLC programming for basic/applied instructions STL/SFC programming and devices.
MELSEC-Q/L/F Structured Programming Manual (Fundamentals)	SH-080782 MODEL CODE: 13JW06	Programming methods, specifications, functions, etc. required to create structured programs.
FXCPU Structured Programming Manual [Device & Common]	JY997D26001 MODEL CODE: 09R925	Devices, parameters, etc. provided in structured projects of GX Works2.
FXCPU Structured Programming Manual [Basic & Applied Instruction]	JY997D34701 MODEL CODE: 09R926	Sequence instructions provided in structured projects of GX Works2.
FXCPU Structured Programming Manual [Application Functions]	JY997D34801 MODEL CODE: 09R927	Application functions provided in structured projects of GX Works2.
FX Series User's Manual - Data Communication Edition	JY997D16901 MODEL CODE: 09R715	Explains N:N link, parallel link, computer link, no protocol communication by RS instructions/FX2N-232IF.
FX3G/FX3U/FX3UC Series User's Manual - Analog Control Edition	JY997D16701 MODEL CODE: 09R619	Describes specifications for analog control and programming methods for FX3G/FX3U/FX3UC Series PLC.
FX3G/FX3U/FX3UC Series User's Manual - Positioning Control Edition	JY997D16801 MODEL CODE: 09R620	Explains the specifications for positioning control of FX3G/FX3U/FX3UC Series and programming procedures

**How to obtain manuals**

For the necessary product manuals or documents, consult with the Mitsubishi Electric dealer from where you purchase your product.


**Incorporated Items**

Check if the following product and items are included in the package:

Main units	Included Items	
FX3U-16M□ to FX3U-128M□	Product	1 unit
	Dust proof protection sheet	1 sheet
	Manuals [Japanese version, English version]	1 manual each
Input/output extension units		
FX2N-32E□, FX2N-48E□	Product	1 unit
	Extension cable	1 cable
	Input/output number label	1 sheet
Input/output extension blocks		
FX2N-8E□, FX2N-16E□	Product	1 unit
	Input/output number label	1 sheet


**1. Outline**

**1.1 Part names**



No.	Name	
[1]	Top cover	
[2]	Battery cover	
[3]	Special adapter connecting hooks (2 places)	
[4]	Expansion board dummy cover	
[5]	RUN/STOP switch	
[6]	Peripheral device connecting connector	
[7]	DIN rail mounting hooks	
[8]	Model name (abbreviation)	
[9]	Input display LEDs (Red)	
[10]	Terminal block covers	
[11]	Extension device connecting connector cover	
	Operation status display LEDs	
[12]	POWER	Green On while power is on the PLC.
	RUN	Green On while the PLC is running.
[12]	BATT	Red Lights when the battery voltage drops.
	ERROR	Red Flashing when a program error occurs.
		Red Lights when a CPU error occurs.
[13]	Output display LEDs (Red)	


With terminal cover open



No.	Name
[1]	Protective terminal covers (FX3U-□M□/□-A is excluded)
[2]	Power supply, Input (X) terminals
[3]	Terminal block mounting screws (FX3U-16M□ terminal block cannot be installed/removed)
[4]	Terminal names
[5]	Output (Y) terminals

1.2 External dimensions and weight

2-φ4.5-diam mounting holes (FX3U-16M□, FX3U-32M□\*1)  
 4-φ4.5-diam mounting holes (FX3U-48M□, FX3U-64M□, FX3U-80M□, FX3U-128M□)  
 FX3U-16M□ and FX3U-32M□\*2 do not have the (\*)-marked mounting holes.



\*1 FX3U-32MR/UA1 uses 4-φ4.5 mounting holes.

\*2 Except FX3U-32MR/UA1

Model name	W: mm (inches)	W1: mm (inches) Direct mounting hole pitches	MASS (Weight): kg (lbs)
FX3U-16M□	130 (5.12")	103 (4.06")	0.6 (1.32lbs)
FX3U-32M□*3	150 (5.91")	123 (4.85")	0.65 (1.43lbs)
FX3U-48M□	182 (7.17")	155 (6.11")	0.85 (1.87lbs)
FX3U-64M□*4	220 (8.67")	193 (7.6")	1.00 (2.2lbs)
FX3U-80M□	285 (11.23")	258 (10.16")	1.20 (2.64lbs)
FX3U-128M□	350 (13.78")	323 (12.72")	1.80 (3.96lbs)

\*3 FX3U-32MR/UA1 is equivalent to FX3U-48M□.

\*4 FX3U-64MR/UA1 is equivalent to FX3U-80M□.

Installation

- 35-mm-wide DIN rail or Direct (screw) mounting (M4)

2. Installation (general specifications)

As for installation of the input/output extension units/blocks, special adapters and expansion boards, refer to FX3U Series User's Manual - Hardware Edition.

INSTALLATION PRECAUTIONS	CAUTION
<ul style="list-style-type: none"> <li>• Use the product within the generic environment specifications described in section 2.1 of this manual. Never use the product in areas with excessive dust, oily smoke, conductive dusts, corrosive gas (salt air, Cl<sub>2</sub>, H<sub>2</sub>S, SO<sub>2</sub> or NO<sub>2</sub>), flammable gas, vibration or impacts, or exposed to high temperature, condensation, or rain and wind. If the product is used in such conditions, electric shock, fire, malfunctions, deterioration or damage may occur.</li> <li>• Do not touch the conductive parts of the product directly to avoid failure or malfunctions.</li> <li>• Install the product securely using a DIN rail or mounting screws.</li> <li>• Install the product on a flat surface. If the mounting surface is rough, undue force will be applied to the PC board, thereby causing nonconformities.</li> <li>• When drilling screw holes or wiring, make sure cutting or wire debris does not enter the ventilation slits. Failure to do so may cause fire, equipment failures or malfunctions.</li> <li>• Be sure to remove the dust proof sheet from the PLC's ventilation port when installation work is completed. Failure to do so may cause fire, equipment failures or malfunctions.</li> <li>• Connect the extension cables, peripheral device cables, input/output cables and battery connecting cable securely to their designated connectors. Unsecured connection may cause malfunctions.</li> <li>• Turn off the power before attaching or detaching the following devices. Failure to do so may cause device failures or malfunctions.                             <ul style="list-style-type: none"> <li>- Peripheral devices, display modules, expansion boards and special adapters</li> <li>- Extension units/blocks and the FX Series terminal block</li> <li>- Battery and memory cassette</li> </ul> </li> </ul>	<p>CAUTION</p>

INSTALLATION PRECAUTIONS	CAUTION
<ul style="list-style-type: none"> <li>• Connect the extension cables, peripheral device cables, input/output cables and battery connecting cable securely to their designated connectors. Unsecured connection may cause malfunctions.</li> <li>• Turn off the power before attaching or detaching the following devices. Failure to do so may cause device failures or malfunctions.                             <ul style="list-style-type: none"> <li>- Peripheral devices, display modules, expansion boards and special adapters</li> <li>- Extension units/blocks and the FX Series terminal block</li> <li>- Battery and memory cassette</li> </ul> </li> </ul>	<p>CAUTION</p>

Notes
<ul style="list-style-type: none"> <li>• When a dust proof sheet is supplied with an extension unit/block, keep the sheet applied to the ventilation slits during installation and wiring work.</li> <li>• To prevent temperature rise, do not install the PLC on a floor, a ceiling or a vertical surface. Install it horizontally on a wall as shown in section 2.2.</li> <li>• Keep a space of 50 mm (1.97") or more between the unit main body and another device or structure (part A). Install the unit as far away as possible from high-voltage lines, high-voltage devices and power equipment.</li> </ul>

WIRING PRECAUTIONS	⚠ DANGER
<ul style="list-style-type: none"> <li>• Cut off all phases of the power supply externally before installation or wiring work in order to avoid damage to the product or electric shock.</li> </ul>	

2.1 Generic specifications

Item	Specification				
Ambient temperature	0 to 55°C (32 to 131°F) when operating and -25 to 75°C (-13 to 167°F) when stored				
Ambient humidity	5 to 95%RH (no condensation) when operating				
Vibration resistance*1	When installed on DIN rail	Fre-quency (Hz)	Accele-ration (m/s <sup>2</sup> )	Half amplitude (mm)	Sweep Count for X, Y, Z: 10 times (80 min in each direction)
		10 to 57	-	0.035	
	When installed directly	10 to 57	-	0.075	
		57 to 150	4.9	-	
Shock resistance*1	147 m/s <sup>2</sup> Acceleration, Action time: 11ms, 3 times by half-sine pulse in each direction X, Y, and Z				
	Noise resistance	By noise simulator at noise voltage of 1,000 Vp-p, noise width of 1 μs, rise time of 1 ns and period of 30 to 100 Hz			
Dielectric withstand voltage*2	1.5kV AC for one minute	Between each terminals and ground terminal			
	500V AC for one minute				
Insulation resistance*2	5MΩ or more by 500V DC megger				
Grounding	Class D grounding (grounding resistance: 100 Ω or less) <Common grounding with a heavy electrical system is not allowed.>*3				
Working atmosphere	Free from corrosive or flammable gas and excessive conductive dusts				
Working altitude	<2000m*4				

\*1 The criterion is shown in IEC61131-2.

\*2 Dielectric withstand voltage and insulation resistance are shown in the following table.

Terminal	Dielectric strength	Insulation resistance
<b>Main units, Input/output extension units/blocks</b>		
Between power supply terminal (AC power) and ground terminal	1.5 kV AC for one minute	5MΩ or more by 500V DC megger
Between power supply terminal (DC power) and ground terminal	500V AC for one minute	
Between 24V DC service power supply connected to input terminal (24V DC) and ground terminal	500V AC for one minute	
Between input terminal (100V AC) and ground terminal	1.5 kV AC for one minute	
Between output terminal (relay) and ground terminal	1.5 kV AC for one minute	
Between output terminal (transistor) and ground terminal	500V AC for one minute	
Between output terminal (triac) and ground terminal	1.5 kV AC for one minute	
<b>Expansion boards, Special adapters, Special function units/blocks</b>		
Between terminal of expansion board and ground terminal	Not allowed	Not allowed
Between terminal of special adapter and ground terminal	500V AC for 1min	5MΩ or more by 500V DC megger
Special function unit/block	Each manual	

For dielectric with stand voltage test and insulation resistance test of each product, refer to the following manual.

→ Refer to FX3U Series User's Manual - Hardware Edition.


\*3 For common grounding, refer to section 3.3.

\*4 The PLC cannot be used at a pressure higher than the atmospheric pressure to avoid damage.

**2.2 Installation location**

Install the PLC in an environment conforming to the generic specifications (section 2.1), installation precautions and notes. For more details, refer to FX3U Series User's Manual - Hardware Edition.


**Installation location in enclosure**




**Space in enclosure**

Extension devices can be connected on the left and right sides of the main unit of the PLC. If you intend to add extension devices in the future, keep necessary spaces on the left and right sides.

**Configuration without extension cable**



**Configuration in 2 stages with extension cable**



**2.2.1 Affixing The Dust Proof Sheet**

The dust proof sheet should be affixed to the ventilation port before beginning the installation and wiring work.

→ For the affixing procedure, refer to the instructions on the dust proof sheet.

Be sure to remove the dust proof sheet when the installation and wiring work is completed.

**2.3 Procedures for installing to and detaching from DIN rail**


The products can be installed on a DIN46277 rail [35mm (1.38") wide]. This section explains the installations of the main units.

For the input/output extension units/blocks and special adapters, refer to the following manual.


→ Refer to FX3U Series User's Manual - Hardware Edition.

**2.3.1 Installation**


- 1) Connect the expansion boards and special adapters to the main unit.
- 2) Push out all DIN rail mounting hooks (below fig.A)



- 3) Fit the upper edge of the DIN rail mounting groove (right fig.C) onto the DIN rail.



- 4) Lock the DIN rail mounting hooks (below fig.D) while pressing the PLC against the DIN rail.



**2.4 Procedures for installing directly (with M4 screws)**

The product can be installed directly on the panel (with screws). This section explains the installation of the main units.

As for the details of the installation/detaching for input extension units/blocks and special adapters, refer to the following manual.

→ Refer to FX3U Series User's Manual - Hardware Edition.

**2.4.1 Mounting hole pitches**


Refer to the External Dimensions (section 1.2) for the product's mounting hole pitch information.

As for the details of the mounting hole pitches for extension unit/block and special adapters, refer to the following manual.

→ Refer to FX3U Series User's Manual - Hardware Edition.

**2.4.2 Installation**

- 1) Make mounting holes in the mounting surface referring to the external dimensions diagram.
- 2) Fit the main unit (A in the right figure) based on the holes, and secure it with M4 screws (B in the right figure).  
The mounting hole pitches and number of screws depend on the product. Refer to the external dimensions diagram.



**3. Power supply/input/output specifications and examples of external wiring**

As for the details of the power supply wiring and input/output wiring, refer to FX3U Series User's Manual - Hardware Edition.

**DESIGN PRECAUTIONS** **⚠ DANGER**

- Make sure to have the following safety circuits outside of the PLC to ensure safe system operation even during external power supply problems or PLC failure. Otherwise, malfunctions may cause serious accidents.
  - 1) Most importantly, have the following: an emergency stop circuit, a protection circuit, an interlock circuit for opposite movements (such as normal vs. reverse rotation), and an interlock circuit (to prevent damage to the equipment at the upper and lower positioning limits).
  - 2) Note that when the PLC CPU detects an error, such as a watchdog timer error, during self-diagnosis, all outputs are turned off. Also, when an error that cannot be detected by the PLC CPU occurs in an input/output control block, output control may be disabled. External circuits and mechanisms should be designed to ensure safe machinery operation in such a case.
  - 3) Note that when an error occurs in a relay, triac or transistor output device, the output could be held either on or off. For output signals that may lead to serious accidents, external circuits and mechanisms should be designed to ensure safe machinery operation in such a case.

**DESIGN PRECAUTIONS** **⚠ CAUTION**

- Do not bundle the control line together with or lay it close to the main circuit or power line. As a guideline, lay the control line at least 100mm (3.94") or more away from the main circuit or power line. Noise may cause malfunctions.
- Install module so that excessive force will not be applied to the built-in programming connectors, power connectors or I/O connectors. Failure to do so may result in wire damage/breakage or PLC failure.

Notes
<ul style="list-style-type: none"> <li>• Simultaneously turn on and off the power supplies of the main unit and extension devices.</li> <li>• Even if the AC power supply causes an instantaneous power failure for less than 10 ms, the PLC can continue to operate.</li> <li>• Even if the DC power supply causes an instantaneous power failure for less than 5ms, the PLC can continue to operate.</li> <li>• If a long-time power failure or an abnormal voltage drop occurs, the PLC stops, and output is turned off. When the power supply is restored, it will automatically restart (when the RUN input is on).</li> </ul>

WIRING PRECAUTIONS	⚠ DANGER
<ul style="list-style-type: none"> <li>• Cut off all phases of the power supply externally before installation or wiring work in order to avoid damage to the product or electric shock.</li> </ul>	

WIRING PRECAUTIONS	⚠ CAUTION
<ul style="list-style-type: none"> <li>• Connect the AC power supply to the dedicated terminals specified in this manual. If an AC power supply is connected to a DC input/output terminal or DC power supply terminal, the PLC will burn out.</li> <li>• Do not wire vacant terminals externally. Doing so may damage the product.</li> <li>• Use class D grounding (grounding resistance of 100Ω or less) with a wire of 2mm<sup>2</sup> or thicker on the grounding terminal of the FX3U Series main unit. However, do not connect the ground terminal at the same point as a heavy electrical system.</li> <li>• When drilling screw holes or wiring, make sure cutting or wire debris does not enter the ventilation slits. Failure to do so may cause fire, equipment failures or malfunctions.</li> <li>• Make sure to properly wire to the terminal in accordance with the following precautions. Failure to do so may cause electric shock, equipment failures, a short-circuit, wire breakage, malfunctions, or damage to the product.                     <ul style="list-style-type: none"> <li>- The disposal size of the cable end should follow the dimensions described in the manual.</li> <li>- Tightening torque should follow the specifications in the manual.</li> </ul> </li> </ul>	


Notes
<ul style="list-style-type: none"> <li>• Input/output wiring 50 to 100 m (164'1" to 328'1") long will cause almost no problems of noise, but, generally, the wiring length should be less than 20 m (65'7") to ensure the safety.</li> <li>• Extension cables are easily affected by noise. Lay the cables at a distance of at least 30 to 50 mm (1.19" to 1.97") away from the PLC output and other power lines.</li> </ul>

**3.1 Wiring**

**3.1.1 Cable end treatment and tightening torque**

For the terminals of FX3U series PLC, M3 screws are used. The electric wire ends should be treated as shown below. Tighten the screws to a torque of 0.5 to 0.8 N·m. Do not tighten terminal screws exceeding the specified torque. Failure to do so may cause equipment failures or malfunctions.


- When one wire is connected to one terminal



**<Reference>**

Terminal Manufacturer	Type No.	Certification	Pressure Bonding Tool
JAPAN SOLDERLESS TERMINAL MFG CO LTD (JST)	FV1.25-B3A	UL Listed	YA-1(JST)
	FV2-MS3		

- When two wires are connected to one terminal



**<Reference>**

Terminal Manufacturer	Type No.	Certification	Pressure Bonding Tool
JAPAN SOLDERLESS TERMINAL MFG CO LTD (JST)	FV1.25-B3A	UL Listed	YA-1(JST)

**3.1.2 Removal and installation of quick-release terminal block**

**Removal** Unscrew the terminal block mounting screw [both right and left screws] evenly, and remove the terminal block.  
**Installation** Place the terminal block in the specified position, and tighten the terminal block mounting screw evenly [both right and left screws].  
 Tightening torque 0.4 to 0.5 N·m  
 Do not tighten the terminal block mounting screws exceeding the specified torque.  
 Failure to do so may cause equipment failures or malfunctions.

\* Pay attention so that the center of the terminal block is not lifted.

**3.2 Power supply specifications and example of external wiring**

As for the details of the power supply specifications and example of external wiring, refer to the following manual.

→ Refer to FX3U Series User's Manual - Hardware Edition.

**3.2.1 Power supply specifications [Main unit, Input/output extension units]**

Item	Specification		
	AC power type	DC power type*6	
Supply voltage	100 - 240V AC	24 V DC	
Allowable supply voltage range	Main unit	16.8 to 28.8V DC*5	
	FX2N-32E□, FX2N-48E□	24V DC +20%, -30%	
Rated frequency	50/60Hz	-	
Allowable instantaneous power failure time	Operation can be continued upon occurrence of instantaneous power failure for 10 ms or less. *4		
	Operation can be continued upon occurrence of instantaneous power failure for 5 ms or less.		
Power fuse	FX3U-16M□ to 32M□*7	250V 3.15A	
	FX3U-48M□ to 128M□	250V 5A	
	FX2N-32E□	250V 3.15A	
	FX2N-48E□	250V 5A	
Rush current	Main unit	30A max. 5ms or less/100V AC 65A max. 5ms or less/200V AC	
	FX2N-32E□, FX2N-48E□	40A max. 5ms or less/100V AC 60A max. 5ms or less/200V AC	
Power consumption*1	FX3U-16M□	30W	25W
	FX3U-32M□	35W	30W
	FX3U-48M□	40W	35W
	FX3U-64M□	45W	40W
	FX3U-80M□	50W	45W
	FX3U-128M□	65W	-
	FX2N-32E□	30W(35VA)	-
	FX2N-48E□	35W(45VA)	30W
24V DC service power supply*2	FX3U-16M□ to 32M□	400mA or less	-
	FX3U-48M□ to 128M□	600mA or less	-
	FX2N-32E□	250mA	-
5V DC builtin power supply*3	Main unit	500 mA or less	
	FX2N-32E□	690mA or less	

\*1 Does not include the power consumption of extension units / special extension units, and of the extension blocks / special extension blocks connected to those units.

For the power (current) consumed by the extension units/blocks for input/output, refer to FX3U Series User's Manual - Hardware Edition.

For the power consumed by the special extension units/blocks, refer to the appropriate manual.

\*2 When input/output extension blocks are connected, the 24V DC service power supply is consumed by the blocks, and the current value to be used by the main unit is reduced.

The AC power (AC input type and DC power type do not have a service power supply.

\*3 Cannot be used to supply power to an external destination. The power is supplied to input/output extension blocks, special extension blocks, special adapters and expansion boards. The following manual shows further information.  
 → Refer to FX3U Series User's Manual - Hardware Edition.

\*4 When the supply voltage is 200 V AC, the time can be changed to 10 to 100 ms by editing the user program.


\*5 When supply voltage is DC 16.8-19.2V, the connectable extension equipment decreases. The following manual shows further information.  
 → Refer to FX3U Series User's Manual - Hardware Edition.

\*6 When attaching high-speed input/output special adapter (FX3U-4HSX-ADP, FX3U-2HSY-ADP) and special function block (FX0N-3A, FX2N-2AD, FX2N-2DA), the number of connectable modules to the main unit is limited, due to the current consumption (internal 24V DC) at startup. The following manual shows further information.  
 → Refer to FX3U Series User's Manual - Hardware Edition.

\*7 250V 5A is specified for the power fuse of FX3U-32MR/UA1.

**3.2.2 Example of external wiring (AC power type)**

100 to 240V AC power is supplied to the main unit and input/output extension units. For the details of wiring work, refer to section 3.1.




\*Class D grounding See section 3.3 for details.

Power supply for loads connected to PLC output terminals

**3.2.3 Example of external wiring (DC power type)**

24V DC power is supplied to the main unit and input/output extension unit. For the details of wiring work, refer to section 3.1.




\* Class D grounding See section 3.3 for details.

Power supply for loads connected to PLC output terminals

**3.3 Grounding**

Ground the PLC as stated below.

- Perform class D grounding. (Grounding resistance: 100 Ω or less)
- Ground the PLC independently if possible. If it cannot be grounded independently, ground it jointly as shown below.



- Use ground wires thicker than AWG14 (2 mm<sup>2</sup>).
- Position the grounding point as close to the PLC as possible to decrease the length of the ground wire.

**3.4 Input specifications and external wiring**

As for the details of the input specifications and external wiring, refer to the following manual.

→ Refer to FX3U Series User's Manual - Hardware Edition.


**3.4.1 Input specifications (24V DC input type)**

Item	Specification	
Number of input points	FX2N-8ER□	4 points (8 points)*1
	FX3U-16M□, FX2N-8EX□	8 points
	FX3U-32M□, FX2N-16EX□, FX2N-32E□	16 points
	FX3U-48M□, FX2N-48E□	24 points
	FX3U-64M□	32 points
	FX3U-80M□	40 points
	FX3U-128M□	64 points

Item		Specification
Input connecting type		Refer to FX3U Series User's Manual - Hardware Edition
Input form		
Input signal voltage	Main units	AC power Type 24V DC +10%, -10%
	Input/output extension unit	DC power Type 24V DC +20%, -30%
Input impedance	Main units	AC power Type 24V DC +10%, -10%
	Input/output extension unit/block	DC power Type 24V DC +20%, -30%
Input signal current	Main units	X000 to X005 3.9kΩ
	Input/output extension unit/block	X006, X007 3.3kΩ
ON input sensitivity current	Main units	X000 to X005 4.3kΩ (Does not apply to FX3U-16M□.)
	Input/output extension unit/block	X006, X007 4.3kΩ
OFF input sensitivity current	Main units	X000 to X005 6mA/24V DC
	Input/output extension unit/block	X006, X007 7mA/24V DC
Input response time	Main units	X000 to X005 5mA/24V DC (Does not apply to FX3U-16M□.)
	Input/output extension unit/block	X006, X007 5mA/24V DC
Input signal form	Main units	X000 to X005 3.5mA or more
	Input/output extension unit/block	X006, X007 4.5mA or more
Input circuit insulation	Main units	X000 to X005 3.5mA or more (Does not apply to FX3U-16M□.)
	Input/output extension unit/block	X006, X007 3.5mA or more/24V DC
Input operation display	Main units	X000 to X005 1.5mA or less
	Input/output extension unit/block	X006, X007 1.5mA or less
Input signal form		Approx. 10ms
Input signal form		<ul style="list-style-type: none"> <li>Sink input: No-voltage contact input NPN open collector transistor</li> <li>Source input: No-voltage contact input PNP open collector transistor</li> </ul>
Input circuit insulation		Photocoupler insulation
Input operation display		LED on panel lights when photocoupler is driven.

\*1 Each value inside ( ) indicates the number of occupied points.

3.4.2 Examples of 24V DC input wiring[AC power type]




\*Class D grounding See section 3.3 for details.

[1]:Main unit, Input/output extension unit (Common to both sink and source inputs)

[2]:Input/output extension block (Common to both sink and source inputs)

3.4.3 Examples of 24V DC input wiring[DC power type]



\*1 Class D grounding See section 3.3 for details.

\*2 Do not connect the (0V), (24V) terminals with others, since they are not available.

[1]:Main unit, Input/output extension unit (Common to both sink and source inputs)

[2]:Input/output extension block (Common to both sink and source inputs)

3.4.4 Instructions for connecting input devices


- In the case of no-voltage contact: The input current of this PLC is 5 to 7 mA/24V DC. Use input devices applicable to this minute current. If no-voltage contacts (switches) for large current are used, contact failure may occur.

<Example> Products of OMRON


Type	Model name	Type	Model name
Microswitch	Models Z, V and D2RV	Operation switch	Model A3P
Proximity switch	Model TL	Photoelectric switch	Model E3S

- In the case of input device with built-in series diode: The voltage drop of the series diode should be approx. 4 V or less. When lead switches with a series LED are used, up to two switches can be connected in series. Also make sure that the input current is over the input-sensing level while the switches are ON.

•Sink input




•Source input




- In the case of input device with built-in parallel resistance: Use a device having a parallel resistance, Rp, of 15 kΩ or more. When the resistance is less than 15 kΩ, connect a bleeder resistance, Rb, obtained from the formula as shown in the following figure.

$$R_b \leq \frac{4R_p}{15-R_p} \text{ (k}\Omega\text{)}$$

•Sink input




•Source input




- In the case of 2-wire proximity switch: Use a two-wire proximity switch whose leakage current, I<sub>l</sub>, is 1.5 mA or less when the switch is off. When the current is 1.5 mA or more, connect a bleeder resistance, Rb, obtained from formula as shown in the following figure.

$$R_b \leq \frac{6}{I_l - 1.5} \text{ (k}\Omega\text{)}$$

•Sink input




•Source input



3.4.5 Input specifications (100V AC input type)

Item	Specification	
Number of input points	FX2N-8EX-UA1/UL	8 points
	FX3U-32MR-UA1	16 points
	FX2N-48ER-UA1/UL	24 points
	FX3U-64MR-UA1	32 points
Input connecting type	Refer to FX3U Series User's Manual - Hardware Edition	
Input form		
Input signal voltage	100V AC to 120V +10%, -15% 50/60Hz	
Input impedance	Approx. 21kΩ/50Hz Approx. 18kΩ/60Hz	
Input signal current	4.7mA/100V AC 50Hz 6.2mA/110V AC 60Hz (70% or less when turned on simultaneously)	
ON input sensitivity current	3.8mA or more	
OFF input sensitivity current	1.7mA or less	
Input response time	Approx. 25ms to 30ms (A high speed receiving is improper)	
Input signal form	Contact input	
Input circuit insulation	Photocoupler insulation	
Input operation display	LED on panel lights when photocoupler is driven.	

### 3.4.6 Examples of 100V AC input wiring



\*1 Class D grounding See section 3.3 for details.

\*2 Do not take input signals from loads generating surge.

[1]:Main unit, Input/output extension unit  
(100V AC input type)

[2]:Input extension block  
(100V AC input type)

### 3.5 Relay output specifications and example of external wiring

As for the details of Instructions for connecting input devices, refer to the following manual.

→ Refer to FX3U Series User's Manual - Hardware Edition.

#### 3.5.1 Relay output specifications

Item	Specification	
Number of output points	FX2N-8ER□	4 points (8 points) <sup>*1</sup>
	FX3U-16MR□, FX2N-8EYR□	8 points
	FX3U-32MR□, FX2N-32ER□, FX2N-16EYR□	16 points
	FX3U-48MR□, FX2N-48ER□	24 points
	FX3U-64MR□	32 points
	FX3U-80MR□	40 points
	FX3U-128MR/ES	64 points
Output connecting type	Refer to FX3U Series User's Manual - Hardware Edition	
Output form	Relay	
External power supply	30V DC or less 240V AC or less ("250V AC or less" if not a CE, UL, cUL compliant item)	
Max. load	Resistance load	2A/point <sup>*2</sup>
	Inductive load	80VA
Min. load	5V DC, 2mA (reference value)	
Open circuit leakage current	-	
Response time	OFF→ON	Approx. 10ms
	ON→OFF	Approx. 10ms
Circuit insulation	Mechanical insulation	
Display of output operation	LED on panel lights when power is applied to relay coil.	

- \*1 Each value inside ( ) indicates the number of occupied points.  
\*2 The total load current of resistance loads per common terminal should be the following value or less.

- 1 output points/common terminal : 2A
- 4 output points/common terminal : 8A
- 8 output points/common terminal : 8A

As for the number of outputs per common terminal, refer to "Chapter 4 interpretation of partition" and the following manual.

→ Refer to FX3U Series User's Manual - Hardware Edition.

#### 3.5.2 Life of relay output contact

The product life of relay contacts considerably varies depending on the load type used. Take care that loads generating reverse electromotive force or rush current may cause poor contact or deposition of contacts which may lead to considerable reduction of the contact product life.

##### 1) Inductive load

Inductive loads generate large reverse electromotive force between contacts at shutdown which may cause arcing. At a fixed current consumption, as the power factor (phase between current and voltage) gets smaller, the arc energy gets larger. The standard life of the contact used for Inductive loads, such as contactors and solenoid valves, is 500 thousand operations at 20VA.

The following table shows the approximate life of the relay based on the results of our operation life test.

Test condition: 1 sec. ON / 1 sec.OFF.

Load capacity	Contact life	
20VA	0.2A/100V AC	3 million times
	0.1A/200V AC	
35VA	0.35A/100V AC	1 million times
	0.17A/200V AC	
80VA	0.8A/100V AC	2 hundred thousand times
	0.4A/200V AC	

The product life of relay contacts becomes considerably shorter than the above conditions when the rush overcurrent is shut down.

→ For countermeasures while using inductive loads, refer to Subsection 3.5.4.

Some types of inductive loads generate rush current 5 to 15 times the stationary current at activation. Make sure that the rush current does not exceed the current corresponding to the maximum specified resistance load.

##### 2) Lamp load


Lamp loads generally generate rush current 10 to 15 times the stationary current. Make sure that the rush current does not exceed the current corresponding to the maximum specified resistance load.

##### 3) Capacitive load

Capacitive loads can generate rush current 20 to 40 times the stationary current. Make sure that the rush current does not exceed the current corresponding to the maximum specified resistance load. Capacitive loads such as capacitors may be present in electronic circuit loads including inverters.

→ For the maximum specified resistance load, refer to Subsection 3.5.1.

### 3.5.3 Example of relay output wiring



#### 3.5.4 Cautions in external wiring

For cautions in external wiring, refer to the following manual.

→ Refer to FX3U Series User's Manual - Hardware Edition.

##### Protection circuit for load short-circuiting

When a load connected to the output terminal short-circuits, the printed circuit board may be burnt out. Fit a protective fuse on the output circuit.

##### Protection circuit of contact when inductive load is used

An internal protection circuit for the relays is not provided for the relay output circuit. It is recommended to use inductive loads with built-in protection circuits. When using loads without built-in protection circuits, insert an external contact protection circuit, etc. to reduce noise and extend the product life.

##### 1) DC circuit

Connect a diode in parallel with the load. Use a diode (for commutation) having the following specifications.

Item	Standard
Reverse voltage	5 to 10 times the load voltage
Forward current	Load current or more

##### 2) AC circuit

Connect the surge absorber (combined CR components such as a surge killer and spark killer, etc.) parallel to the load. Select the rated voltage of the surge absorber suitable to the output used. Refer to the table below for other specifications.

Item	Standard
Electrostatic capacity	Approx. 0.1μF
Resistance value	Approx. 100 to 200Ω

##### Interlock

Loads, such as contactors for normal and reverse rotations, that must not be turned on simultaneously should have an interlock in the PLC program and an external interlock.

##### Common mode

Use output contacts of the PLC in the common mode.

### 3.6 Transistor output specifications and example of external wiring

As for the details of the transistor output specifications and external wiring, refer to the following manual.

→ Refer to FX3U Series User's Manual - Hardware Edition.

#### 3.6.1 Transistor output specifications


Item	Specification		
Number of output points	FX3U-16MT/□, FX2N-8EYT□	8 points	
	FX3U-32MT/□, FX2N-32ET□, FX2N-16EYT□	16 points	
	FX3U-48MT/□, FX2N-48ET□	24 points	
	FX3U-64MT/□	32 points	
	FX3U-80MT/□	40 points	
	FX3U-128MT/ES(S)	64 points	
Output connecting type	Refer to FX3U Series User's Manual - Hardware Edition		
Output form	FX3U-□□MT/□S(-A), FX2N-□ET, FX2N-48ET-D, FX2N-□EYT, FX2N-8EYT-H	Transistor(Sink)	
	FX3U-□□MT/□SS, FX2N-□ET-ESS/UL, FX2N-48ET-DSS, FX2N-□EYT-ESS/UL	Transistor(Source)	
External power supply	5 to 30V DC		
Max. load	Resistance load	FX3U-□□MT/□, FX2N-□ET, FX2N-□ET-□, FX2N-□EYT, FX2N-□EYT-ESS/UL	0.5A/point <sup>*1</sup>
		FX2N-8EYT-H	1A/point <sup>*2</sup>
	Inductive load	FX2N-16EYT-C	0.3A/point <sup>*3</sup>
		FX3U-□□MT/□, FX2N-□ET, FX2N-□ET-□, FX2N-□EYT, FX2N-□EYT-ESS/UL	12W/24V DC <sup>*4</sup>
	FX2N-8EYT-H	24W/24V DC <sup>*5</sup>	
	FX2N-16EYT-C	7.2W/24V DC <sup>*6</sup>	
Min. load	-		
Open circuit leakage current	0.1mA or less/30V DC		
ON voltage	1.5V or less		

Item		Specification	
Response time	OFF → ON	Main unit Y000 to Y002	5μs or less/10mA or more (5 to 24V DC)
		Y003 or more	0.2ms or less/200mA or more (at 24V DC)
	ON → OFF	Main unit Y000 to Y002	5μs or less/10mA or more (5 to 24V DC)
		Y003 or more	0.2ms or less/200mA or more (at 24V DC)
Input/output extension units/blocks*7		0.2ms or less/200mA or more (at 24V DC)	
Circuit insulation		Photocoupler insulation	
Display of output operation		LED on panel lights when photocoupler is driven.	


- \*1 The total load current of resistance loads per common terminal should be the following value or less.  
 - 1 output point/common terminal : 0.5A  
 - 4 output point/common terminal : 0.8A  
 - 8 output point/common terminal : 1.6A  
 As for the number of outputs per common terminal, refer to "Chapter 4 interpretation of partition" and the following manual.  
 → Refer to FX3U Series User's Manual - Hardware Edition.
- \*2 The total load current of resistance loads per common terminal should be the following value or less.  
 - 4 output points/common terminal : 2A  
 As for the number of outputs per common terminal, refer to the following manual.  
 → Refer to FX3U Series User's Manual - Hardware Edition.
- \*3 The total load current of resistance loads per common terminal should be the following value or less.  
 - 16 output point/common terminal : 1.6A  
 As for the number of outputs per common terminal, refer to the following manual.  
 → Refer to FX3U Series User's Manual - Hardware Edition.
- \*4 The total of inductive loads per common terminal should be the following value or less.  
 - 1 output point/common terminal : 12W/24V DC  
 - 4 output points/common terminal : 19.2W/24V DC  
 - 8 output points/common terminal : 38.4W/24V DC  
 As for the number of outputs per common terminal, refer to "Chapter 4 interpretation of partition" and the following manual.  
 → Refer to FX3U Series User's Manual - Hardware Edition.
- \*5 The total of inductive loads per common terminal should be the following value or less.  
 - 4 output points/common terminal : 48W/24V DC  
 As for the number of outputs per common terminal, refer to the following manual.  
 → Refer to FX3U Series User's Manual - Hardware Edition.
- \*6 The total of inductive loads per common terminal should be the following value or less.  
 - 16 output points/common terminal : 38.4W  
 As for the number of outputs per common terminal, refer to the following manual.  
 → Refer to FX3U Series User's Manual - Hardware Edition.
- \*7 The response time is as follows in the FX2N-8EYT-H.  
 - OFF → ON : 0.2ms or less/1A  
 - ON → OFF : 0.4ms or less/1A

### 3.6.2 External Wiring of Transistor Output

#### 1. External Wiring of Sink Output Type



#### 2. External Wiring of Source Output Type



### 3.6.3 Cautions in external wiring

For cautions in external wiring, refer to the following manual.  
 → Refer to FX3U Series User's Manual - Hardware Edition.

#### Protection circuit for load short-circuits

A short-circuit at a load connected to an output terminal could cause burnout at the output element or the PCB. To prevent this, a protection fuse should be inserted at the output. Use a load power supply capacity that is at least 2 times larger than the total rated fuse capacity.

#### Contact protection circuit for inductive loads

When an inductive load is connected, connect a diode (for commutation) in parallel with the load as necessary. The diode (for commutation) must comply with the following specifications.

Item	Guide
Reverse voltage	5 to 10 times of the load voltage
Forward current	Load current or more

#### Interlock

Loads, such as contactors for normal and reverse rotations, that must not be turned on simultaneously should have an interlock in the PLC program and an external interlock.

### 3.7 Triac output specifications and example of external wiring

As for the details of the triac output specifications and external wiring, refer to the following manual.


→ Refer to FX3U Series User's Manual - Hardware Edition.

### 3.7.1 Triac output specifications

Item		Specification
Number of output points	FX3U-32MS/ES, FX2N-16EYS, FX2N-32ES	16 points
	FX3U-64MS/ES	32 points
Output connecting type		Refer to FX3U Series User's Manual - Hardware Edition
Output form		Triac (SSR)
External power supply		85 to 242V AC
Max. load	Resistance load	0.3A/point <sup>*1</sup>
	Inductive load	15VA/100V AC, 30VA/200V AC
Min. load		0.4VA/100V AC, 1.6VA/200V AC
Open circuit leakage current		1mA/100V AC, 2mA/200V AC
Response time	OFF → ON	1ms or less
	ON → OFF	10ms or less
Circuit insulation		Photo-thyristor insulation
Display of output operation		LED on panel lights when photo-thyristor is driven.

- \*1 The total load current of resistance loads per common terminal should be the following value or less.  
 - 4 output points/common terminal : 0.8A  
 - 8 output points/common terminal : 0.8A  
 As for the number of outputs per common terminal, refer to "Chapter 4 interpretation of partition" and the following manual.  
 → Refer to FX3U Series User's Manual - Hardware Edition.

### 3.7.2 External Wiring of Triac Output



### 3.7.3 Cautions in external wiring

For cautions in external wiring, refer to the following manual.

→ Refer to FX3U Series User's Manual - Hardware Edition.

#### Protection circuit for load short-circuits

A short-circuit at a load connected to an output terminal could cause burnout at the output element or the PCB. To prevent this, a protection fuse should be inserted at the output.

#### Micro current load

The PLC's internal Triac output circuit is equipped with a turn-off C-R absorber. When connecting a very low current load of "0.4VA/100V AC or less, or 1.6VA/200V AC or less", please connect a surge absorber parallel to the load.

Select the rated voltage of a surge absorber that is suitable for the load being used. Refer to the table below for other specifications.

Item	Guide
Static electricity capacity	Approx. 0.1μF
Resistance value	Approx. 100 to 200Ω

#### Interlock

Loads, such as contactors for normal and reverse rotations, that must not be turned on simultaneously should have an interlock in the PLC program and an external interlock.

## 4. Terminal block layouts


For details on the terminal block layout, refer to the following manual.

→ Refer to FX3U Series User's Manual - Hardware Edition.

#### Interpretation of partition

The partition of the output terminals (see following figure) indicates the range of the output connected to the same common.

Example: FX3U-48MT/ES



This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

#### Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; opportunity loss or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

### ⚠ For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi Electric.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.